

# MOTOROLA U6 PEBL FACEPLATE INSTALLATION GUIDE

Any information shown here belongs to AccessoryGeeks.com. Individuals who use this information in any sort of illegal way will be tracked down and prosecuted.



You will need a T3 and T5 driver for this faceplate installation.

### Step 1:

Remove the inside LCD panel. The inside of your Motorola PEBL U6 is attached to your phone with adhesive tape. It will be easier to peel off if you heat it with a hair dryer before detaching it. Do not overheat or melt your LCD panel or phone. After you heat up the panel gently peel off the panel.



Step 2:

Remove the first top two screws with a T5 driver and then remove the bottom two screws with a T3 driver.



### Step 3:

Place the new faceplate on top and use the existing screws that you already have to put everything together again. On the back faceplate, simply remove the back cover and place the new one on.



### Step 4:

Reattach the inside panel.

