

SEARCH

[Contact](#) [FAQs](#) [Return Policy](#) [Site map](#) [Privacy Policy](#)

 [Cellphone Accessories](#)

 [Cellphone Batteries](#)

 [Clearance Sale Sale!](#)

 [GIFT ITEM!](#)

- [Motorola V220 Accessories](#)
- [Motorola RAZR V3 Accessories](#)
- [Motorola E815 Accessories](#)
- [LG VX-6100 Accessories](#)

Promotion

**FREE
SHIPPING
in the USA**



Cell phone Accessories

- [AUDIOVOX](#)
- [BLACKBERRY](#)
- [HANDSPRING](#)
- [INNOSTREAM](#)
- [KYOCERA](#)
- [QUALCOMM](#)
- [LG](#)
- [MOTOROLA](#)
- [NEC](#)
- [NEXTEL](#)
- [NOKIA](#)

[HOME](#) > [FAQ](#) > [FACEPLATE INSTALLATION](#) > [LG L1200](#)

LG L1200 FULL HOUSING INSTALLATION

1. LG L1200 faceplate installation guide from Accessorygeeks.com



2. There are 4 screws.

- PANASONIC
- SANYO
- SAMSUNG
- SIEMENS
- SHARP
- SONY ERICSSON
- TOSHIBA
- UNIVERSAL
- APPLE IPOD



3. Remove all screws from LG L1200



4. Remove the LCD cover



5. View of the inside of LCD Panel - LG L1200



6. LG L1200 faceplate installation guide from Accessorygeeks.com



7. Detach the face cover from LG L1200



8. Remove the LCD from the face cover



9. LG L1200 faceplate installation guide from Accessorygeeks.com



10. Disassemble the face plate - LG L1200



11. Replace a new faceplate - LG L1200



12. LG L1200 faceplate installation guide from Accessorygeeks.com



13. Reattach face cover onto LG L1200



14. Inside view of face cover



15. Apply all screws - LG L1200



16. LG L1200 faceplate installation guide from Accessorygeeks.com



17. Now, LG L1200 new faceplate installation complete

